

## DC-DC 測試

2025.7.10 官孝澤

## 摘要

• 因為在Layout 圖上有錯誤的關係,所以要把線以及電阻阻值更正







R200 10k→1k


## 將這塊小板子插入DC-DC背面供電12V






- 量測R12(0歐姆): 應該為0.13V左右
- 上面的電源供應器給6V,接到這兩端,然後電流從0~10開始轉<mark>(電流不要停太久線會燒掉)</mark>







## 測試版子

Board R12 Voltage		R200 (10k>1k)
1		
2		
3	0.125	V
4	0.127	V
5	0.127	V
6	0.121	V
7	0.129	
8	0.118	V
9	0.129	
10	0.125	V
11		
12	0.125	V
13		
14	0.13	V
15	0.108	V
16		
17	0.125	V
18		
19	0.129	V
20	0.129	V